
AQUAPHOR®water filters



OWNER'S MANUAL

AQUAPHOR RO-101S, RO-102S, RO-101S EU, RO-102S EU, RO-101S IL, RO-102S IL (in further RO) REVERSE OSMOSIS SYSTEM

Contents

3
4
5
6
7
8
9
10
10
12
12
13
14

WARNING

Please read this manual carefully before you proceed with the installation. Your failure to follow any of the attached instructions or operating parameters may lead to the product's failure and possible property damage.

Save the manual for future reference.

Thank you for your purchase of this Aquaphor RO. With proper installation and maintenance, this system will provide you with premium quality drinking water. The technology used in the Aquaphor RO enriches the filtered water with minerals in controlled quantities.

This water is highly beneficial for the body as it helps to normalize the physiological processes.

If you have any questions or concerns, please contact our customer service department at email sales@aquaphor.com. We are always happy to answer any questions you may have regarding our product.

Introduction

Aquaphor RO operates by removing contaminants from water at the molecular level. By using your household water pressure to squeeze the water against a special membrane, the water molecules are separated from any impurities that exist.

Rejected dissolved solids are automatically rinsed away through the drain leaving you with only high-quality, delicious water for your use.

1. Operational parameters

Operating temperatures:	Maximum 38 °C (100.4 °F)	Minimum 5 °C (41 °F)
Operating pressure:	Maximum 0.63 MPa (6.3 bar / 91.4 psi)	Minimum 0.19 MPa (1.9 bar / 27.6 psi)
	The operating pressure in your ho 24 hour period to attain the maxin MPa (6.3 bar / 91.4 psi), then a pre will be required.	num pressure. If it is above 0.63
Dimensions (length x height x width):	371 x 420 x 190 mm	
Maximum flow rate membrane cartridge (water temperature +25 °C (77 °F) with a constant pressure of 0.4 MPa (4 bar / 58.02 psi)	For Aquaphor RO-101S, Aquaphor RO-101S EU, Aquaphor RO-101S IL – 50 GPD For Aquaphor RO-102S, Aquaphor RO-102S EU, Aquaphor RO-102S IL – 100 GPD	
Cleaned water to drained water ratio (water temp. no less than +20 °C / 68 °F)	1:4-1:6	
Mass no more than	6.2 kg / 13.66 lbs	
pH parameters:	Maximum 10	Minimum 4
Iron:	Maximum 0.3 ppm	
TDS (Total Dissolved Solids):	Maximum 2000 ppm	
Turbidity:	Maximum 1 NTU	
Hardness:	Recommended water hardness should not exceed 350 ppm as CaCO ₃ (20.5 grains per gallon). The system will operate with hardness over 350 ppm (20.5 gpg), but the membrane cartridge life may be shortened. The addition of a water softener may lengthen the membrane cartridge life.	

Table 1. The dependence of minimum necessary operating pressure of the water purifier from mineralization

Mineralization		Minimum pressure		
mg/L, ppm	gpg	MPa	bar	psi
100.1	5.8	0.2	2	29.01
200.2	11.7	0.25	2.5	36.26
300.3	17.5	0.3	3	43.51
400.4	23.4	0.4	4	58.02
500.5	29.2	0.6	6	87.02

ATTENTION!

The efficiency of RO depends on the incoming tap water mineralization and tap water pressure (please see table 1). The recommended operation of RO requires tap water pressure of at least 0.2 MPa (2 bar / 29.01 psi).

When tap water pressure is less than illustrated in the table 1, it is highly recommended to install a booster pump in order to obtain drainage ratio.

ATTENTION!

Air-gap device must be used in connecting your RO system to the drain pipe (in accordance with EN 1717 and NSF53 requirements)

2. Safety instructions

WARNING: RO must be applied to potable water only.

It is highly recommended that a water treatment specialist be hired to install and maintain this appliance.

When installing the appliance into a local water supply, it is recommended that you conduct a full water analysis. If the water analysis does not correspond with the requirements, the life of the filtration and membrane cartridges may be significantly reduced. In this case, it is recommended to use auxiliary water treatment systems (e.g. mechanical filter, de-ironing filter with, or along-side a water softener). Only use microbiological safe water with your Reverse Osmosis system appliance.

CAUTION: Do not use water that is microbiologically unsafe or water of unknown quality without adequate disinfection before or after using the appliance.


CAUTION: Reverse Osmosis water should not be run through copper tubing as the purity of the water will leach copper and cause an objectionable taste in the water. Additionally, it will form pinholes in the tubing. Be sure to follow any state or local regulations.

CAUTION: The Reverse Osmosis system is designed to be connected to cold water only. Never run warm or hot water through your appliance.

3. Product assembly:

N°	Component Qu		
1	RO Housing assembly (1)		
2	Cartr	idges:	
	2.1 Preliminary water treatment block:		
		Replacement filter cartridge K5 (for Aquaphor RO-101S, Aquaphor RO-102S, Aquaphor RO-101S IL, Aquaphor RO-102S IL) (3)	1 pc
		Replacement filter cartridge K1 (for Aquaphor RO-101S EU, Aquaphor RO-102S EU) (3)	1 pc
		Replacement filter cartridge K2 (2)	1 pc
	2.2	Reverse Osmosis membrane block:	
		Replacement membrane cartridge Aquaphor RO-50S (for Aquaphor RO-101S, Aquaphor RO-101S EU, Aquaphor RO-101S IL) (4)	1 pc
		Replacement membrane cartridge Aquaphor RO-100S (for Aquaphor RO-102S, Aquaphor RO-102S EU, Aquaphor RO-102S IL) (4)	1 pc
	2.3.	Water conditioning block:	
		Replacement filter cartridge K7M (for Aquaphor RO-101S, Aquaphor RO-102S, Aquaphor RO-101S IL) (5)	1 pc
		Replacement filter cartridge K7BM (for Aquaphor RO-101S EU, Aquaphor RO-102S EU, Aquaphor RO-102S IL) (5)	
3 Connecting tubes (6):			
	Tube 3/8" (d 9,5 mm) Tube 1/4" (d 6,35 mm) (drain)		1 pc
			1 pc
	Tube	1/4" (d 6,35 mm) with pressed metal bushing	1 pc
4	Drain saddle (7)		1 set
5	Connection node (8)		1 set
6	Clean water faucet (9) 1s		1 set
7	Service cap (pre-installed in housing) for:		
Replacement filter cartridges K5 (for Aquaphor RO-101S, Aquaphor RO-102, Aquaph RO-101S IL, Aquaphor RO-102S IL), K1 (for Aquaphor 101S EU, Aquaphor 102S EU), K (for Aquaphor RO-101S, Aquaphor RO-102S, Aquaphor RO-101S IL), K7BM (for Aquaphor RO-101S EU, Aquaphor RO-102S IL) (10a)		D1S IL, Aquaphor RO-102S IL), K1 (for Aquaphor 101S EU, Aquaphor 102S EU), K2, K7M Iquaphor RO-101S, Aquaphor RO-102S, Aquaphor RO-101S IL), K7BM	3 pc
	Mem	brane cartridge (pre-installed in housing) (10b)	1 pc
8	Operation Manual 1 pc		

Figure 1. Product assembly



To open the lid, please turn the three plastic latch screws on the cover 90 degrees counterclockwise (figure 2).

Figure 2. How to open the top lid




4. RO design and operation principles

- RO housing (1) consists of an upper plate, with four collectors fixed onto it, to place the replacement cartridges and the RO-hydro automatic unit RO. The upper lid comes with a decorative cover, fixed in place with three plastic latches. An integral part of the RO housing is the treated water storage tank (6). Treated water goes into the storage tank upon exiting the membrane cartridge. This storage tank ensures availability of the required amount of filtered water always.
- Preliminary water treatment block (2, 3) includes replacement filter cartridge includes replacement filter cartridge K5 (for RO-101S, RO-102S, Aquaphor RO-101S IL, Aquaphor RO-102S IL) (3) or cartridge K1 (for RO-101S EU, RO-102S EU) (3) and K2 (2). The preliminary water treatment block removes any impurities that can damage membrane cartridge, such as ferric hydroxide and active chlorine.
- Reverse Osmosis membrane block (4) includes the replacement membrane cartridge Aquaphor RO-50S (for RO-101S, RO-101S EU, Aquaphor RO-101S IL) or Aquaphor RO-100S (for RO-102S, RO-102S EU, Aquaphor RO-102S IL) and purifies water by removing organic compounds, non-organic compounds, and salts while softening water.
- Water conditioning block (5) includes the mineralizing cartridge K7M (for RO-101S, RO-102S, Aquaphor RO-101S IL) or K7BM (for RO-101S EU, RO-102S EU, Aquaphor RO-102S IL). The water conditioning block eliminates unwanted odors and flavors from water while mineralizing the water.

Figure 3. RO main components


- 1 RO housing assembly;
- 2, 3 Preliminary water treatment block;
- 4 Reverse Osmosis membrane block;
- 5 Water conditioning block;
- 6 Storage tank



How RO works

The water coming from the cold water mains enters RO and passes through the preliminary water treatment block. From there, water enters the Reverse Osmosis membrane block via the automatic check valve. The unit housing the membrane cartridge has two outlets: the treated water outlet and the drain water outlet. On its way to the drain, the water will also pass through a flow restrictor. The flow restrictor flushes the drain water that goes down the drain.

The treated water enters the storage tank that has a built-in membrane. This separates the tank into two chambers: storage and technical. The storage chamber contains the fully purified drinking water, while the technical chamber contains water from the mains. As clear water collects, water from the mains is forced from the technical chamber into the drain, also preventing the accumulation of clear water. When the storage tank is full, the automatic check valve cuts off the water intake into RO



When the clean water faucet is opened, water from the mains enters the technical chamber via the shutoff valve and forces treated water from the storage chamber through the faucet via the conditioning block. The automatic check valve then triggers and opens water supply to the ROstorage tank.

5. RO installation


ATTENTION! Only install your RO by a qualified plumber who is certified to perform the installation in accordance with state law.

Locate the appropriate installation place for the faucet and RO. Take care to ensure that the delivery tubes are pulled freely, without over bending. RO must be installed on a flat, even solid surface as installation on an uneven surface may cause vibration or noise. Additionally, RO must be located away from heat sources, such as kitchen ovens, hot water supply pipes, dishwashers or washing machines, or at least isolated from such heat sources.

ATTENTION!

Air-gap device must be used in connecting your RO device to the drain pipe.

Without the air gap, wastewater could siphon back into the drinking supply. This can happen when a city main is shut off, causing a drain-down of the system with plumbing done improperly.



Please connect drain tube with air-gap device (not included in delivery set). Please use below scheme to connect your RO.

You may use the same air-gap device as for your dishwasher machine or order special air-gap for ROsystem. Please contact with service to receive more information.






Figure 4b. Optional RO installation scheme (only for countries where EN 1717 or NSF 53 is not mandatory)



Connection node assembly

- Turn the water off at the cold water main.
- Open the kitchen faucet to discharge pressure into the water line.
- Unscrew the nut from the flexible line cap, leading to the faucet on the cold water main.

Figure 5. Connection node installation scheme



ATTENTION! Residual water will be left inside of the flexible tube after discharge of water.

When disconnecting the flexible line, please use a 200 ml or similar size container to drain the water left behind in the tube.

Clean water

- Screw the cap nut off the connection node and on the cold water main thread.
- Screw the cap nut off the flexible line, and then on the connection node thread.
- Set the shutoff valve on the connection node to the closed position and then make sure that the connection is completely leak-proof by supplying water to the cold water main.
- Connect tube (follow the instructions below to correctly connect the tubes).


ATTENTION! Make sure that the sealing O-Ring is located correctly in its place and not damaged during installation.

Connection of tubes

Pull the locking clip (2) off the plastic plug (1). Then install the previously wetted end of the tube (3) into the fitting piece approx.15 mm up to the stop. Next, put the locking clip (2) back.

Make sure that the tube (3) is tightened correctly: the tube should not be pulled out by force greater than 8-10 kgf.


Figure 6. Connection of tubes



Disconnection of tubes

Pull the locking clip (2) off the plastic plug (1), then pull the tube (3) out by applying pressure on the face of the connecting piece.

Figure 7. Disconnection of tubes




6. Clean water faucet installation

- Drill the hole in the sink (table top) 12 mm diameter:
- Put on the thread tail of the faucet (1) rubber gasket (2), decorative stand (3), rubber gasket (4) and insert the faucet into the hole in the sink;
- Underneath the sink, put rubber gasket (5) plastic (6) and metal (7) lock washers on the thread bushing and screw on the fastening nut (8);
- Put on the plastic pipe with pressed metal bushing (9) and screw on the nut (10) onto the tail end of the faucet.

ATTENTION!

- When you replace the original tap with a different one, there may be noise when you open it, and clean water flow reduction from the tap may occur.
- When you replace the original pipes with the longer ones, there may be noise and clean water flow reduction from the tap.
- If the water filter has not been used for a long time, the valves may turn on, making short-term noise. It is not a sign of the system malfunction.
- Open the clean water tap fully when you use the water filter, otherwise noise may occur. It is not a sign of the water filter malfunction.

Figure 8. Tube connecting to the clean water faucet procedure




7. Drain saddle installation

ATTENTION! This step is only for only for countries where EN 1717 or NSF 53 is not mandatory. In accordance with EN 1717 and NSF 53 air-gap device must be used in connecting your RO system to the drain pipe.

It is best install the drain saddle on the sink drain before the siphon trap or bend (the drain saddle on most drain pipes is of ~40 mm diameter).


- Apply the part of the collar with the fitting to the pipe to determine the optimal position of the collar and the pipe hole.
- 2. Drill a 7 mm hole in the planned tube location on the tube pipe.
- 3. Remove the cut circle from the sealing gasket (1) (see figure 9a).

Figure 9a. Drain saddle components



- Remove the protective tape (2) from the sealing gasket (1). Place the sealing gasket (1) on the collar inner side, so that the hole in the gasket meets the hole in the collar fitting.
- Install the collar onto the pipe, carefully aligning the hole in the fitting with the drilled hole; tighten the bolts (3). The bolts must be tightened evenly in such a way that the two parts of the collar are located in parallel.
- Put the plastic nut onto the drain tube (1/4") so that the tube is protruding from the other side of the nut by a length of 20 mm (see figure 9b).

Figure 9b. Drain saddle installation



To eliminate any noise from the water in the drain saddle, push the tube deeper into the pipe.


8. Starting RO

To start RO, you must connect the supply tube and carry out the flushing procedure of filter and membrane cartridges.

Step 1

Connect the incoming tubes according to the diagram below (figure 10). The tube connection scheme is illustrated on figure 6

Figure 10. Incoming tubes connection



Step 2

Preparing RO for operation and flushing the preliminary water treatment block

Table 2. Positions of RO cartridges in preparation for operation

Position	Cartridge type
1	K2
2	K5 / K1
3	Service Cap (figure 1, 10b)
4	Service Cap (figure 1, 10a)

- Make sure two service caps are installed in the housing. (table 2).
- · Remove the shrink film from the cartridges.
- · Rinse the sealing O-Rings of the cartridges.
- Remove other service caps and install cartridges according to table 2.
- Set the shutoff valve on the connection node into the open position, as shown on figure 4.
- Leave the clean water faucet open for 10 minutes.

The noise during the flushing of the cartridges is not a defect.

· Close the clean water faucet.

Step 3

Flushing the membrane cartridge unit

- Set the shutoff valve on the connection node into the closed position, as shown on figure 5.
- Remove the service plug and install membrane cartridge.
- Interchange the K5 / K1 and K2 cartridges.
- Turn the shutoff valve on the connection node into the open position.
- Open the clean water faucet, then wait for the water to start flowing.
- Let the water flush through RO for 1 hour.*
- · Close the clean water faucet.

· Step 4

Flushing the conditioning cartridge K7M / K7BM $\,$

- Set the shutoff valve on the connection node into the closed position, as shown on figure 5.
- Remove the service plug and install the conditioning cartridge.
- Turn the shutoff valve on the connection node into the open position.
- Fill in the storage tank. This will take 30–50 minutes, depending on water pressure.
- Open the clean water faucet and then wait until all of the water flows out from the storage tank.
- · Repeat these steps two more times.
- · Close the clean water faucet.
- When the tank is full, RO is ready for operation.

NOTE: In total, the general flushing of filter and membrane cartridges and startup time will take you about 3 hours.


9. Replacing cartridges

The membrane cartridge service life directly depends on operation of the preliminary water treatment unit (cartridges K5 / K1 and K2). Therefore, it is always very important to replace the filtering cartridges in a timely manner.

Replacing cartridges K5 / K1 and K2 (figure 11):


 Set the shutoff valve on the connection node into the closed position, and then open the clean water faucet to discharge any pressure.

Figure 11. Cartridge installation



- Rotate the used filter cartridges K5 / K1 and (or) K2 in a clockwise direction to remove the used cartridge.
- Install the new cartridges K5 / K1 and (or) K2 according to Table 2. Rotate the cartridge counter clockwise to a click.
- Rotate the membrane cartridge in a clockwise direction to remove it.
- 5. Make sure the service cap is installed in the housing (figure 1, position 10b), figure 12.
- Set the shutoff valve on the connection node into the open position.

Figure 12. Installation of the membrane cartridge service plug



^{*} Depending on the storage, transportation and operation conditions, the complete flushing of membrane cartridge may take up to 24 hours.

ATTENTION! Under-twisting the cartridge to the final position (accompanied by a click) can cause leaks.

- Open the clean water faucet and flush the preliminary water treatment cartridges for around 20–30 minutes.
- 8. Set the shutoff valve on the connection node into the closed position.
- Install the membrane cartridge instead of the service cap.
- Interchange the positions of K5 / K1 and K2 cartridges.
- Set the shutoff valve on the connection node into the open position and close the clean water faucet.
- 12. Make sure that RO connections are sealed.

Replacing the conditioning cartridge K7M / K7BM

- Set the shutoff valve on the connection node into the closed position; then open the clean water faucet to discharge pressure.
- Rotate the used conditioning cartridge K7M / K7BM in a clockwise direction to remove it.
- 3. Install a new conditioning cartridge. Rotate the cartridge counter clockwise to a click.
- Set the shutoff valve on the connection node into the open position; then wait for all of the water to flow out from the storage tank through the clean water faucet.
- 5. Then close the clean water faucet.
- When the tank is filled, your RO is ready for operation.
- 7. Make sure that RO is properly sealed.

Replacing the membrane cartridge

- Set the shutoff valve on the connection node into the closed position, and then open the clean water faucet to discharge pressure.
- 2. Rotate the used membrane cartridge in a clockwise direction to remove it.
- Install a new membrane cartridge in place of the removed one. Rotate the cartridge counter clockwise to a click.
- 4. Turn the shutoff valve on the connection node to the open position.

- Flush the water through RO for duration of approximately 1 hour.*
- 6. Close the clean water faucet.
- When the tank is filled, RO is ready for operation.
- 8. Make sure that RO is properly sealed.

ATTENTION! To avoid any incorrect installation of the membrane cartridge and the resulting loss of sealing of the RO connections, it is not recommended to dissemble it without a fully qualified maintenance specialist. If the RO connections are leaking, immediately close the tap on the connection unit and check the cartridges for correct installation.

10. Recommended filter replacement

The frequency at which the filter and membrane cartridges should be replaced depends on the quality of the water that enters the appliance. Contact your water treatment specialist for replacement filters and parts.

NOTE: The installation of the RO appliance on a pre-treated water supply will greatly increase the life of its filters.

Table 3. Recommended filter replacement

Filter Cartridges	Recommended Replacement (months)
Replacement filter cartridge K5 / K1 (1)	6
Replacement filter cartridge K2 (2)	6
Replacement membrane cartridge RO-50S / RO-100S (3)	12
Replacement filter cartridge K7M (4)	12
Replacement filter cartridge K7BM (4)	6

Once purchased, the cartridges can be stored for three years from the manufacturing date.

^{*} Depending upon storage, transportation and operation conditions, complete flushing of the membrane cartridge may take up to 24 hours.

11. Recommended filter maintenance

The frequency at which the filter and membrane cartridges should be replaced depends on your tap water quality.

Note: Any filter that demonstrates reduced water production or a slower rate of flow is likely to be overdue for a change.

WARNING: Shut off the water to the appliance before beginning any maintenance work.

Replacement of filter cartridge K5 / K1 (1)

Reduces dirt and other sediment particle matter of 5 micron or larger in the incoming water.

Replace the K5 / K1 filter cartridge every three months

Replacement of filter cartridge K2 (2)

This reduces free chlorine from the incoming water and protects the membrane from any chlorine degradation. Changing frequency of the replacement filter cartridge K2 should be based on the free chlorine levels in the incoming water

If the free chlorine is 1 ppm or less, then the replacement filter cartridge K2 should be replaced once a year. If the free chlorine level is greater than 1 ppm, then the replacement filter cartridge K2 should be replaced once in every six months.

Replacement membrane cartridge RO-50S / RO-100S (3)

The semi-permeable membrane cartridge (3) separates the majority of the remaining suspended solids and most of the dissolved solids from the water molecules. These separated impurities are then washed down the drain.

The membrane cartridge (3) is critical for the effective reduction of total dissolved solids (TDS). The treated water should be tested periodically to verify that the appliance is performing satisfactorily. A noticeable change in water quality and taste may occur. If this happens, it is an indicator that a filter change is needed. Replace the membrane cartridge at least once a year.

Replacement filter cartridge K7M / K7BM (4)

The replacement filter cartridge K7M or K7BM (4) is the final stage of filtration. It filters the water and enriches it with useful minerals that improve not only the taste, but also maintains the correct drinking water salt balance. You should replace the post filter every 6 months.

12. Warranty

Installation, operational, storage and transportation rules described in this manual should be maintained. The manufacturer is not responsible for operation of the Aquaphor RO and possible consequences, in case if:

- RO or components have visible mechanical, thermal or chemical damages;
- requirements for installation and operation of the RO described in present manual were not carried out.

The lifetime of the parts of the RO is:

RO case – 5 years* starting from the manufacturing date;

Connecting pipes – 3 years* starting from the manufacturing date;

Purified water faucet – 3 years* starting from the manufacturing date;

The lifetime (capacity) of the replacement filter cartridges is:

Name of the replacement filter cartridge	Lifetime (capacity) of the replacement filter cartridge
K5 / K1	6 months ⁽¹⁾
K2	6 months ⁽¹⁾
Membrane cartridge RO-50S / RO-100S	1,5 years ⁽²⁾
K7M	1 year
K7BM	6 months ⁽¹⁾

(1) Lifetime (capacity) of the replacement filter cartridges may depend on incoming water quality. If in the source water contains large amounts of insoluble impurities then cartridges K5 / K1 and K2 should be replaced after 1–3 month of operation.

(2) Lifetime of the membrane cartridge is depended upon the efficiency of the prefiltration and water conditioning units.

^{*} Regardless of the operation starting date.

Data listed above based on the average consumption of the purified water 10–12 liters per day.

Please replace cartridges in a proper time.

Warranty period of the RO operation (except for replacement filter cartridges and membrane cartridge) is 2 year starting from the purchase date. The storage period of the RO before operation is maximum 3 years 1.5 year in the temperature range from +5 to +38 °C (40 to 100 °F) with intact packing.

If you have any claims regarding the operation of your RO, please contact the seller or manufacturer.

Manufacturer is not responsible for operational faults occurred due to inappropriate installation or maintenance.

Manufacturer is not responsible for the operational faults occurred due to inappropriate replacement cartridges.

Warranty only valid for use in accordance with instruction and using only unexpired filter cartridges. Failure to timely replace filter cartridges or follow installation or maintenance voids the warranty.

13. Troubleshooting

If the appliance has difficulties working, use the Appliance shutoff valve to shut off the incoming water to the appliance.

Problem	Possible Cause	Solution	
Faucet flow rate is very slow.	Shutoff valve is not completely opened.	Open the shutoff valve and faucet completely	
Slow flow rate or no water from faucet	One of the replacement cartridges needs to be replaced	Check which cartridge needs to be replaced according to the resource life, and replace the cartridge. In order to determine which cartridge needs to be replaced, please see the instructions below	
The storage tank fills very slowly or does not	How to check if the cartridges lifespan is over.		
fill at all.	 Close the shutoff valve and open the faucet in order to release the pressure. 		
	– Replace the cartridges K5, K1, K2, K7M, K7BM with service caps.		
	– Open the shutoff valve.		
	 Open the faucet, flush the water from the unit until the flow rate decreases and the tank is empty. 		
	If water continues to run faster than 50 ml/min, install the cartridges one at a time K5, K1, K2, K7M, K7BM and according the flow rate decreases determinate which of the cartridge (or several cartridges) needs to be replaced.		
	If water runs slower than 50 ml/min, then the membrane needs to be replaced.		
	Turn off the shutoff val	ve and open it every time you replace each	
If any other faults are id	entified, please contact ou	r customer service department at or email sales@	

aquaphor.com

Warranty coupon AQUAPHOR RO

Date of Sell	
Seller's stamp	
Seller's signature	

Please visit our website and register your RO at aquaphor.com/register for manufacturer's warranty.

Installation information

Installation is carried out: Name of the company which carried out installation:	
Name of the service engineer:	
Service engineer's signature:	
Client's signature:	
For installation, operational and technical maintenance, please, contact:	



Manufacturer:

Aquaphor International OÜ, L. Tolstoi 2A, Sillamäe, Estonia, 40231. www.aquaphor.com The model number, date of manufacture and quality control are shown on the product's serial number label. The manufacturer reserves the right to make improvements to the design of the water purifier withoutreflecting them in the passport. **AQUAPHOR RO models: AQUAPHOR RO-101S AQUAPHOR RO-102S EU AQUAPHOR RO-102S** 5 AQUAPHOR RO-101S IL 2 3 **AQUAPHOR RO-101S EU** 6 AQUAPHOR RO-102S IL Product serial number: